



Introduction

Name: ZL-6008B UV aging testing machine



Specifications

Hot Selling Environmental UV Accelerated aging Test Chamber for Plastic and Coatings

Tel: [+86-769-8928 0588](tel:+86-769-89280588)

Fax: [+86-769-8928 0988](tel:+86-769-89280988)

Website: www.zltester.com

E-mail: Zhongli@zltester.com

Address: [No.62, Xinhe Management of Area, Wanjiang District, Dongguan city, Guangdong province ,China](#)



1. manufacturer
2. 9 year

2014 Hot Selling Environmental UV Accelerated aging Test Chamber for Plastic and Coatings is ideal for water exposure aging test of non-metallic materials such as paint, rubber. Since UV is the main cause for polymer degradation, while water accelerate aging process. 2014 Hot Selling Environmental UV Accelerated aging Test Chamber for Plastic and Coatings can flexibly simulate outdoor exposure aging so it is of high value in testing relatively weather ability of different samples. Standards met include GB/T14522-1999 ISO11507.1997,etc.

Parameters:

Total power	1.65kw
Number of lamps	3
UV wavelength	340nm(UVA, UVB,UVC optional)
mercury flow	47Lmin
shaft rotation speed	>3r.p.m
jig size	75×150mm
weight	53kg
vertical distance between sample and shaft	155mm
sample number	24
heating temperature	40-60℃
maximum spraying interval	99h 59min
size	840×420×565mm(L×W×H)
Total test time	999.9h

Tel: [+86-769-8928 0588](tel:+86-769-89280588)

Fax: [+86-769-8928 0988](tel:+86-769-89280988)

Website: www.zltester.com

E-mail: Zhongli@zltester.com

Address: [No.62, Xinhe Management of Area, Wanjiang District, Dongguan city, Guangdong province ,China](#)